

## Paintable Collection | FLUTED INSTALLATION INSTRUCTIONS

#### **PRECAUTIONS**



Always wear work gloves, safety glasses and mask when cutting this product.

#### TOOLS

- 100% polyurethane construction glue (3 tubes per 100 ft<sup>2</sup> or 10 m<sup>2</sup>)
- Caulking gun
- Electric mitre saw
- Table saw
- Level

- · Measuring tape
- Cutter
- · Pneumatic finish nailer (#23 gauge finish nail)
- Stepladder

WALL PANEL NEEDS TO BE GLUED AND NAILED FOR A SUCCESSFUL INSTALLATION AND TO PREVENT FUTURE WARPING. FAILURE TO COMPLY WITH INSTALLATION INSTRUCTIONS SHALL VOID APPLICATION OF THE WARRANTY.

Do not install over material other than drywall or plywood.

#### MAKE SURE YOUR KNIVES AND SAWBLADES ARE IN TOP CONDITION.

**FIRST,** check that wall is level from floor to ceiling and edge-to-edge. If not, adjust accordingly.

#### STEP 1:


Apply a line of 100% polyurethane glue (1/2" (1.3 cm) from the edge) and an Xinside the rectangle on the back of the wall panel.



# STEP 2: Position first panel vertically at bottom right. Make sure each panel and each column is level.

#### STEP 3:

Nail panel in place with #23 gauge nails. Nail at the base of the tabs at an angle to prevent the nails from showing.



### STEP 4: $\rightarrow$ Installation of next panels


- Repeat Step 1. • Set panel **B** against **A**.
- Repeat Step 3.

#### **STEP 5:** End a column

Cut any excess of wall panel flush with top of wall.

#### STEP 6: Start a new column

Use remaining piece of previous column or start with a new piece. Repeat Step 1, 2 and 3



#### STEP 7: Last column

Cut panel on the left to fit available space.

Note: The Paintable Collection is unfinished - it is recommended to paint the panel with acrylic primer and paint to seal. Consult with your local paint store for specific product information.

Stacked Wood guarantees the conformity of its products when they are installed according to installation instructions and maintained in an environment where ambient humidity ranges between 35% and 55%: before, during and after installation.

PRIOR TO INSTALLATION, PLACE CARTONS IN ORIGINAL PACKAGING FLAT ON THE FLOOR OF PLANNED ROOM.